






Box Contents

- **Prodigy Case**
- **Prodigy Quick Installation Guide**
- Accessories:
 - ⊕ ODD Bay Screw Brackets: x 2
 - ⊕ Cable Clip: x 1
- Screws:
 - ⊕ Thumbscrews M3: x 4 (For ODD)
 - ⊕ Standard Screw 6-32 Hex: x 4 (For PSU)
 - ⊕ Standard Screw 6-32*6mm Flat: x 7 (For MB & ODD Bay Screw Brackets)
 - ⊕ Standard Screw 6-32*10mm Round: x 5 (For securing HDD trays)
 - ⊕ Standard Screw M3*5mm Round: x 12 (For 2.5" SSD & ODD)

* Contents and specifications subject to change without notice.







Front



Top




Back




Side

Basic Installation

Removing side panels




a. Remove thumbscrews




b. Remove side panels




Installing 5.25" drives




a. Remove front panel by pushing tabs from inside chassis



b. Remove ODD bay blank and drive bay cover from front panel




c. Slide drive into drive bay




d. Secure with screws (Thumbscrews M3)




Installing 3.5" drives




a. Remove hard disk tray



b. Install drive by bending rails of tray to the side




c. Slide tray into place




d. If needed, add extra 6-32*10mm Round screw for increased stability




Installing 2.5" drives



a. Remove hard disk tray




b. Install drive using M3*5mm Round screws




c. Slide tray into place




Installing 2.5" drives




a. Remove FlexCage™ and position drive(s) on PSU cage



b. Secure with screws (M3*5mm Round)




c. Remove FlexCage™ and position drive on floor




d. Secure with screws (M3*5mm Round)



Installing 2.5" drives



a. Slide drives into place




b. Secure with screws (M3*5mm Round)



Features

Control Panel



A. Power button

B. Reset button

C. Headphone jack


D. Microphone jack

E. SuperSpeed USB3.0 ports







Top Fan Installation (120mm)




a. Remove top filter



b. Install fans




c. Secure with screws




d. Replace top filter




Front Fan Installation



a. Remove front panel by pushing tabs from inside chassis




b. Install fans (If necessary, remove FlexCage™ & ODD cage)




c. Secure with screws



Rear Fan Installation



a. Install fan




b. Secure with screws






FlexCage™ Hard Disk Rack




a. Press tabs on HDD cage




b. Pull to remove

Removing FlexCage™




a. Remove plastic rail from bottom of ODD cage




b. Remove screws from bottom of HDD cage




Rotating FlexCage™




a. Remove and rotate the HDD cage



b. Secure screws from bottom of HDD cage




c. Rotate the plastic rail and secure screws from bottom of ODD cage




d. Insert HDD cage from other side




Replacing ODD bay blank




a. Remove FlexCage™



b. Remove front panel, then remove ODD cage by unscrewing the screws




c. Position ODD bay screw brackets and ODD bay blank




d. Secure with screws (6-32*6mm Flat)




Power Supply Installation




a. Remove PSU Back Plate




b. Secure PSU Back Plate on PSU




c. Slide PSU into place



d. Secure with screws



PSU Filter



PSU Filter



bitfenix

Bitfenix Co., Ltd.

3F, No.79, Sec. 1, Xintai 5th Rd.,

Xi Zhi District, New Taipei City, Taiwan, R.O.C.

For the most updated information, please visit our official website: <http://www.bitfenix.com>

© 2012 BITFENIX Co., Ltd. All Rights Reserved. All trademarks are registered to their respective owners.

Ver 1.0 : 2012/05



