
## **Quick Installation Guide**




## Spectre ARGB SE Kit

Spectre ARGB Fan	
Dimensions	120 x 120 x 25mm
Operating Voltage	12Vdc ± 5%
Starting Voltage	5Vdc
Max. Current	0.35A
Speed	1200r.p.m±10%
Air Flow(CFM)	42 CFM±10%
Air Pressure(H <sup>2</sup> O)	0.67 mm H <sup>2</sup> O
Noise dB(A)	22 dB(A)
Bearing Type	Rifle Bearing (RFB)
Accessories	Fan Screw x 4
Operating Voltage	5Vdc ± 5%


















- On Short press to turn on the light.
  Long press to switch to remote control.
  - Press this key to enter the auto play mode when it is on.
- Off) Press to turn off the light.
- (s+) Accelerate the fan speed.
- s-) Slow down the fan speed.
- (M+) select the mode up.

- (M-) select the mode down.
- Brightness +
- Brightness –
- (M/B) Long Press to switch to motherboard control.
- Press the buttons of different colors and the corresponding light colors will appear.









## **Check More**



If you would like to use Fan Kit Controller with other BitFenix controller or any help please create a support ticket on BitFenix Website https://www.bitfenix.com/support/



火鳥官方網站 https://www.bitfenix.com/?lang=zh-hant



火鸟官方微博



BitFenix Official Website https://www.bitfenix.com/



火鳥台灣臉書粉絲專頁 https://www.facebook.com/bitfenixtw



火鸟淘宝官方店铺